

INSTALLATION INSTRUCTIONS

SWIRL COAT

Coverage rates may vary depending on the porosity of the substrate.
This application is recommended for experienced installers only.

1 Preparation

- Ensure the concrete is sufficiently cured to the recommended minimum of 28 days from completion.
- Diamond grind the substrate. The surfaces must be clean and dry, free from all traces of loose material, old coatings, curing compounds, release agents, laitance, oil, and grease, etc. This must be completed by diamond grinding or a suitable cleaning method.
- To check that all traces of oil and other contaminants have been completely removed, sprinkle a few drops of water over the surface. If all water is quickly absorbed, the surface is sufficiently oil and grease-free.
- If water forms into globules that remain on the surface, further thorough treatment of the substrate is necessary.
- Substrate compression strength should be at least 25MPa, cohesive bond strength at least 1.5MPa and moisture content below 4%.
- Repair and fill cracks with EPO100EP Epoxy Putty or Concrete Repair Kit.

The surface must be dry before the application of the product. Acid or wet etching is not recommended.

2 Prime Coat

- Apply a prime coat of EPO100T® Tinted Epoxy at a rate of 6m²/L, 10% of 150 Epoxy Thinners is recommended depending on the substrate.
- Leave to cure for approximately 24 hours or until touch dry.

If applying a second coat of epoxy more than 72 hours after the prime coat, lightly sand the existing coat prior to application.

3 Base Coat

- Apply a second coat of EPO100T® Tinted Epoxy at a rate of 6m²/L, 10% of 150 Epoxy Thinners is recommended depending on the substrate.
- Leave to cure for approximately 24 hours or until touch dry.
- Check the surface has been entirely sealed to prevent bubbles and pinholes in the Metallic Marble Coat. If in doubt, apply an additional coat of EPO100T® at the same coverage rate.

If applying the Swirl Coat more than 72 hours after the base coat, lightly sand the floor prior to application.

NOTE: Refer to individual TDS & SDS for mixing instructions, pot life, recommended PPE during preparation & application of products.

1800 437 699 | SALES@ALLPURPOSECOATINGS.COM.AU | 16 HAWKINS CRESCENT, BUNDAMBA, QLD 4304.

INSTALLATION INSTRUCTIONS APC V0324



INSTALLATION INSTRUCTIONS

SWIRL COAT

4 Swirl Coat

Swirl Base Coat

This will be the dominant colour on your floor.

- Mix EPO100G® Epoxy Glaze as per specifications and add 350E Epoxy Tint at a ratio of 3L per 30L of EPO100G® to achieve high opacity.
- While wearing spike shoes, pour the Swirl Coat Base mix at a rate of 1m²/L. Spread using a lint free roller, squeegee or trowel.

Swirl Coat Highlights

Applied to the wet swirl coat base.

- Swirl Coat Highlights don't have a required spread rate, and should be completed to achieve the desired finish.
- Mix EPO100G® Epoxy Glaze as per specifications and add 350E Epoxy Tint at a ratio of 3L per 30L of EPO100G® to achieve high opacity.
- While wearing spike shoes, apply your Swirl Coat Highlights coat over your Swirl Base Coat as desired. Apply using a roller, squeegee, squeeze bottle and/or stirring stick.
- Leave to cure for approximately 24 hours or until touch dry.

Do not use thinners on this coat.

If applying the next coating more than 72 hours after the Swirl Coat, lightly sand the floor prior to application.

5 Optional - High Gloss Clear Coat

- While wearing spike shoes, apply the high gloss coat of EPO100G® Epoxy Glaze at a rate of 6m²/L. Apply using a lint free roller.
- Leave to cure for approximately 24 hours or until touch dry.

If applying the First UV Top Coat more than 72 hours after the High Gloss Clear Coat, lightly sand the floor prior to application.

6 First UV Top Coat

- Lightly sand the floor with 180 grit sandpaper. If using a polyvac, ensure you are using sandpaper, not sanding screens. Sanding screens may cause contamination to the surface.
- Apply the first UV top coat of Sparta60 Polyaspartic at a rate of 6m²/L. Apply using a lint free roller.
- Leave to cure for approximately 4 hours or until touch dry.

If applying a second top coat of Sparta60 Polyaspartic more than 24 hours after the entrapment coat, lightly sand the floor prior to application.

NOTE: Refer to individual TDS & SDS for mixing instructions, pot life, recommended PPE during preparation & application of products.

INSTALLATION INSTRUCTIONS

SWIRL COAT

7 Second UV Top Coat

- Apply the second UV top coat of Sparta60 Polyaspartic at a rate of 6m²/L. Apply using a lint free roller.
- Leave to cure for approximately 24 hours or until touch dry.
- Full chemical cure in 7 days.

This should only be applied by an experienced installer.

Independent slip testing is to be conducted after application to provide certified documentation that the coating meets or exceeds the required slip rating.

NOTE: Refer to individual TDS & SDS for mixing instructions, pot life, recommended PPE during preparation & application of products.

1800 437 699 | SALES@ALLPURPOSECOATINGS.COM.AU | 16 HAWKINS CRESCENT, BUNDAMBA, QLD 4304.

INSTALLATION INSTRUCTIONS APC V0324

