



INSTALLATION INSTRUCTIONS

ULTRA FLAKE

Grip Finish

Coverage rates may vary depending on the porosity of the substrate.

1 Preparation

- Ensure the concrete is sufficiently cured to the recommended minimum of 28 days from completion.
- Diamond grind the substrate. The surfaces must be clean and dry, free from all traces of loose material, old coatings, curing compounds, release agents, laitance, oil, and grease, etc. This must be completed by diamond grinding or a suitable cleaning method.
- To check that all traces of oil and other contaminants have been completely removed, sprinkle a few drops of water over the surface. If all water is quickly absorbed, the surface is sufficiently oil and grease-free.
- If water forms into globules that remain on the surface, further thorough treatment of the substrate is necessary.
- Substrate compression strength should be at least 25MPa, cohesive bond strength at least 1.5MPa and moisture content below 4%.
- Repair and fill cracks with EPO100EP Epoxy Putty or Concrete Repair Kit.

The surface must be dry before the application of the product. Acid or wet etching is not recommended.

2 Prime Coat

- Apply a prime coat of EPO100T® Tinted Epoxy at a rate of 6m²/L, 10% of 150 Epoxy Thinners is recommended depending on the substrate.
- Leave to cure for approximately 24 hours or until touch dry.

If applying a second coat of epoxy more than 72 hours after the prime coat, lightly sand the existing coat prior to application.

3 Base Coat & Ultra Flake Broadcast

- Mix in 750ml - 1L (1.1kg-1.5kg) of Quartz Shield per 4.5kg box of Ultra Flake.
 - Nano Ultra Flake coverage: 10m²/box.
 - Small and Large Ultra Flake coverage: 12-15m²/box.

If installed correctly, the system is expected to achieve the following;

- Quartz Shield 25: P5 Slip Rating
- Quartz Shield 40: P4 Slip Rating
- Apply a second coat of EPO100T® Tinted Epoxy at a rate of 6m²/L, 10% of 150 Epoxy Thinners is recommended depending on the substrate.
- While the coating is still wet and wearing spiked shoes, broadcast the mix up and out evenly until refusal. Avoid throwing the flake and quartz directly at the floor as you will experience clumping.
- Leave to cure for approximately 24 hours or until touch dry.

This application is based on a full broadcast of Ultra Flake and Quartz Shield.

Continuously change your position while broadcasting, throwing the mix at a distance may cause the quartz to separate from the flake.

NOTE: Refer to individual TDS & SDS for mixing instructions, pot life, recommended PPE during preparation & application of products.



INSTALLATION INSTRUCTIONS

ULTRA FLAKE

Grip Finish

4 Entrapment Coat

- Broom the surface to knock off any sharp flake or quartz.
- Use a garden blower or vacuum to remove excess and unbound flake from the surface.
- Apply the entrapment coat of Sparta60 Polyaspartic at a rate of 3-4m²/L.
- Leave to cure for approximately 4 hours or until touch dry.

The UV Top Coat must be applied within 24 hours after the entrapment coat, as the floor can not be sanded.

5 UV Top Coat

- Apply the top coat of Sparta60 Polyaspartic at a rate of 5-6m²/L.
- Leave to cure for approximately 24 hours or until touch dry.
- Full chemical cure in 7 days.

Independent slip testing is to be conducted after application to provide certified documentation that the coating meets or exceeds the required slip rating.

NOTE: Refer to individual TDS & SDS for mixing instructions, pot life, recommended PPE during preparation & application of products.

1800 437 699 | SALES@ALLPURPOSECOATINGS.COM.AU | 16 HAWKINS CRESCENT, BUNDAMBA, QLD 4304.

INSTALLATION INSTRUCTIONS APC V0324

