



INSTALLATION INSTRUCTIONS

HYPER FLAKE SIGNATURE SERIES

Essential Finish

Coverage rates may vary depending on the porosity of the substrate.

1 Preparation

- Ensure the concrete is sufficiently cured to the recommended minimum of 28 days from completion.
- Diamond grind the substrate. The surfaces must be clean and dry, free from all traces of loose material, old coatings, curing compounds, release agents, laitance, oil, and grease, etc. This must be completed by diamond grinding or a suitable cleaning method.
- To check that all traces of oil and other contaminants have been completely removed, sprinkle a few drops of water over the surface. If all water is quickly absorbed, the surface is sufficiently oil and grease-free.
- If water forms into globules that remain on the surface, further thorough treatment of the substrate is necessary.
- Substrate compression strength should be at least 25MPa, cohesive bond strength at least 1.5MPa and moisture content below 4%.
- Repair and fill cracks with EPO100EP Epoxy Putty or Concrete Repair Kit.

The surface must be dry before the application of the product. Acid or wet etching is not recommended.

2 Prime Coat

- Apply a prime coat of EPO100T® Tinted Epoxy at a rate of 4-6m²/L, 5% of 150 Epoxy Thinners is recommended depending on the substrate.
- Leave to cure for approximately 24 hours or until touch dry.

If applying a second coat of epoxy more than 72 hours after the prime coat, lightly sand the existing coat prior to application.

3 Base Coat & Hyper Flake Signature Series Broadcast

- Mix the Hyper Flake Signature Series together in the box or bucket prior to your broadcast to allow for flakes and fines to be even throughout the dry mix.
- Apply a second **THIN** coat of EPO100T® Tinted Epoxy at a rate of 6 - 8m²/L, 10% 150 Epoxy Thinners is recommended depending on the substrate.
- Wearing spike shoes and whilst the coating is still wet, broadcast the Hyper Flake Signature Series up and out evenly until refusal, avoid throwing the flake directly at the floor as you will experience clumping.
 - Hyper Flake Signature Series coverage: 8 - 12m²/4.5kg box.
- Leave to cure for approximately 24 hours or until touch dry.

If the base coat of EPO100T® is applied too thick the 'fines' of the Hyper Flake Signature Series will be swallowed by the epoxy, causing the finish to be uneven.

This application is based on a full broadcast of Hyper Flake Signature Series.

NOTE: Refer to individual TDS & SDS for mixing instructions, pot life, recommended PPE during preparation & application of products.

1800 437 699 | SALES@ALLPURPOSECOATINGS.COM.AU | 16 HAWKINS CRESCENT, BUNDAMBA, QLD 4304.

INSTALLATION INSTRUCTIONS APC V0324





INSTALLATION INSTRUCTIONS

HYPER FLAKE SIGNATURE SERIES

Essential Finish

4 Entrapment Coat

- Heavily scrape or broom the surface to knock off any sharp flake.

Do not sand the Hyper Flake Signature Series prior to the entrapment coat.

- Use a garden blower or vacuum to remove excess and unbound flake from the surface.
- Apply the entrapment coat.
 - Option: 500T Tetrathane® at a rate of 4m²/L, leave to cure for approximately 24 hours or until touch dry.
 - Option: Sparta60 Polyaspartic at a rate of 4m²/L, leave to cure for approximately 4 hours or until touch dry.
 - Option: Sparta Guard at a rate of 4-6m²/L.

Only one coat of Sparta Guard is required. Experienced installers only.

If applying a second top coat of Sparta60 Polyaspartic more than 24 hours or Tetrathane more than 72 hours after the entrapment coat, lightly sand the floor prior to application.

5 UV Top Coat

Ensure the same product is used for both the Entrapment and UV Top Coat.

- **Optional Slip Resistance** - Mix Dimple into your top coat at a rate of 250g/20L. If using Sparta60, add 20% Epoxy Thinners (e.g for 20L of Sparta60, use 250g of Dimple and 4L of Epoxy Thinners).
- Apply the top coat.
 - Option: 500T Tetrathane® at a rate of 6m²/L.
 - Option: Sparta60 Polyaspartic at a rate of 6m²/L.

If a Sparta Guard Polyaspartic entrapment coat has been applied, no Top Coat is required.

- Leave to cure for approximately 24 hours or until touch dry.
- Full chemical cure in 7 days.

Dimple can not exceed 500g per 20L.

Independent slip testing is to be conducted after application to provide certified documentation that the coating meets or exceeds the required slip rating.

NOTE: Refer to individual TDS & SDS for mixing instructions, pot life, recommended PPE during preparation & application of products.

1800 437 699 | SALES@ALLPURPOSECOATINGS.COM.AU | 16 HAWKINS CRESCENT, BUNDAMBA, QLD 4304.

INSTALLATION INSTRUCTIONS APC V0324

